

TESTING TIMERS INSTRUCTIONS

USING THE WATCH MODE:

- Press the "Watch Mode" button to use the digital watch.

CHANGE THE CLOCK MODE, DATE AND TIME:

- Hold the "Watch Mode" button for three seconds. Immediately the screen should begin blinking.
- While the screen is blinking, scroll through the changeable options by pressing the "Watch Mode" button.
- If the aspect of the watch you want to change is blinking, press the "Test Mode" button to make changes.
- There are two ways to exit and return back to the watch:
 1. Scroll through all changeable screens (by pressing the "Test Mode" button a total of six times), or
 2. Do not press any button for 15 seconds.
- To make additional changes, repeat this process.

PICK YOUR TEST SECTION:

- When the watch is not being changed (not blinking), press the "Test Mode" button to enter the home screen.
- Immediately the text "CHOOSE" will appear with an indicating arrow pointed to the "Test Mode" button.
- Press the "Test Mode" button. The first preset timing screen for the test will appear.
- Continue to press the "Test Mode" button to scroll through the different sections.

START THE TEST:

- To begin a specific test, press the "Start/Pause" button to start the timer.
- For more information about the displayed screen, visit the How It Works page at <http://testingtimers.com/>

QUIT THE TEST:

- In order to prevent accidental quitting, the watch must first be paused.
- To pause the timer, press the "Start/Pause" button while the test is running.
- Next, press the "Version/Quit" button.
- Immediately the text "QUIT?" will appear along with "Y" and "N".
- To quit the test, press the "Test Mode" button, indicated by "Y".
- To remain in the test, press the "Start/Pause" button, indicated by "N".
- To resume the test, press the "Start/Pause" button again.

CHECK YOUR WATCH:

- First make sure that the watch mode is not activated and the watch is not in the middle of a test.
- To check the watch properly, the watch should be on the home screen or "CHOOSE" screen.
- Press the "Version/Quit" button to check the watch version.
- Three pieces of information will flash: the specific watch, the version year, and version number.
- An additional way to check the watch is to check the code on the back of the watch (Ex. AB1106203998).
- The first letter on the code represents the watch:
 - A: aTest Timer
 - S: sTest Timer



FOR MORE INFORMATION, PLEASE CONTACT:
INFO@TESTINGTIMERS.COM